

PEAK

PREVENTIVE MAINTENANCE



www.mahlkoenig.de



PEAK RECOMMENDED SPARE PARTS LIST

AMOUNT	DESCRIPTION	ARTICLE NUMBER
1	Hopper with lid (without logo)	309560
1	Cover grind adjustment black, complete	104903
1	Front panel black, complete, from serial no. 614575	701468
1	Collecting tray	306340
1	Back panel black 100 - 127 V, complete	105304
1	Back panel black 200 - 240 V, complete	105305
1	Operating capacitor 60 μ F 250 VAC, 100 - 120 V	701084
1	Operating capacitor 16 μ F 440 VAC, 200 - 240 V	257326
1	Starting capacitor 40 μ F 250 VAC, 100 - 120 V	105261
1	Starting capacitor 20 μ F 450 VAC, 200 - 240 V	310717
1	Device feet high, from serial no. 602646, set of 4	700882
1	Device feet low, till serial no. 602646, set of 4	104613
1	Micro switch service pack, till serial no. 614574	701461
1	Rocker switch service pack, till serial no. 614574	104593
1	Portafilter mounting, service pack, from serial no. 614575	701460
1	Portafilter mounting, till serial no. 614574	307425
1	Portafilter support UL, service pack	104597
1	Fan 12 VDC, service pack	105308
1	Circuit breaker CBE-7A, 100 - 120 V	308383
1	Circuit breaker CBE-4A, 200 - 240 V	700680

PEAK RECOMMENDED SPARE PARTS LIST

AMOUNT	DESCRIPTION	ARTICLE NUMBER
1	Power board 100 - 240 V 10 W	105081
1	Push button "single shot" (LED red)	103091
1	Push button "double shot" (LED red)	103092
2	Processor board	104620
2	Display incl. LED	104584
1	Fine adjustment adapter, service pack	104591
1	Locking grind adjustment, service pack	104590
1	Seal ring	701119
1	Burr set	103993
10	Silicone flapper (50 Hz)	103576
10	Silicone flapper (60 Hz)	104792
1	Shock absorber, set of 3	309410
1	Adapter bolts, set of 3	105310

PEAK BASIC STOCK PROPOSAL CLEANING PROCESS

1. CLEANING:

Always unplug the coffee grinder before cleaning.

- Apply dry cleaning only. If necessary use suitable mild „dish“ washer detergent
- No alkaline cleaning agent must be used for cleaning (affects-flavour)
- Do not spray coffee grinder with water and/or steam (risk of short circuit)
- Clean your grinder periodically, at least once a week.
- Please use MAHLKÖNIG GRINDZ™

Cleaning of housing:

- Use paper towel along with mild dish washer detergent to clean the housing, cover lid and inside the hopper

Cleaning of spout tube:

- Use a vacuum cleaner to exhaust the discharge tube. The use of brushes can lead to the damage of the built-in flappers resulting in an inaccurate grinding result.

Periodic checking of the grinder, burrs and grinding quality must only be performed by competent service personnel and/or trained staff.

2. ROUTINE CHECK:

Indications:

- Reduction of the output of the grinder.
- Temperature increase of the ground coffee
- Inconsistent grind
- Increased amount of dust
- Grinder clogs more often

3. MAINTENANCE:

Short-term maintenance every 2 weeks

- Outside cleaning including the hopper
- Use GRINDZ™

Long-term maintenance once a year

- Thorough cleaning of the grinder including the opening of the grinder housing and removing of all coffee residues
- Change of burrs
- Checking calibration and re-calibrate, if necessary



Hemro International AG

Längenstrasse 34 | 8184 Bachenbülach, Schweiz

T: +41 44 864 18 00 | F: +41 44 864 18 01

info@hemrogroup.com | www.hemrogroup.com