






Valid from 25th August 2015
Supersedes all previously issued spare parts lists

Subject to change without prior notice.




Model: ProM Espresso 100-120V 50/60Hz

ARTICLE NO.	DRAWING NO.	DESCRIPTION
100485	2	Hopper ProM Espresso with lid
100745	3	Top housing assembly. ProM Espresso
310624	4	Gasket grinder casing
100580	5	EK8 built-in grinder fine 100-120V 50/60Hz
310183	6	Spout gasket




Model: ProM Espresso 100-120V 50/60Hz

ARTICLE NO.	DRAWING NO.	DESCRIPTION
100994	7	Portafilter holder ProM Espresso
-	8	Front panel complete UL (see page 5)
310033	9	Side panel left
311050	10	Side panel right ProM Espresso (without button)
310433	12	Rocker switch round
310986	13	Power cord, US
100976	13	Power cord, JP (JET)
310170	14	Lucent ring
310225	15	Base plate
310537	16	Fuse holder
100201	17	Safety fuse F2,5A L fast
310706	18	Rubber feet, pack of 4
100249	19	EMC-board 115V




Model: ProM Espresso 100-120V 50/60Hz

ARTICLE NO.	DRAWING NO.	DESCRIPTION
310468	20	O-ring 71 x 2m
100427	21	Spout cover ProM Espresso
100200	21a	Treaded pin with peak M4x20
310709	22	Micro switch, service pack
310058	23	Upper panel
310714	24	Small parts set, cover
100748	25	Seal ring hopper ProM
100295	26	Frontpanel Display ProM Espresso
100817	27	Rear Panel Display ProM Espresso
100816	28	Bracket Display ProM Espresso
100394	29a	Screw ProM Espresso Display 2,5*6
100395	29b	Screw for thermoplast 3x8




Model: ProM Espresso 100-120V 50/60Hz

ARTICLE NO.	DRAWING NO.	DESCRIPTION
100994	7	Portafilter holder ProM Espresso
-	8	Front panel complete UL
102009	30	Front panel ProM Espresso, service pack
310711	31	Small parts set, front panel
310626	32	Power board 100-120V
310062	33	Residue tray ProM
310713	34	Start button, service pack



Model: ProM Espresso 100-120V 50/60Hz

ARTICLE NO.	DRAWING NO.	DESCRIPTION
100580	5	EK8 built-in grinder fine 100-120V 50/60Hz
101017	40	Grinder casing cover EK8, service pack
101019	41	Grinding disc set EK8 pro, service pack
101022	42	Adjustment EK8 ProM Espresso, service pack
101021	43	Belt / wheel EK8, service pack
102180	44	Spout EK8 100-120V, service pack
101020	45	Rotating burr carrier EK8, service pack
101023	46	Damper EK8, service pack



Model: ProM Espresso 100-120V 50/60Hz

ARTICLE NO.	DRAWING NO.	DESCRIPTION
310091	-	Rubber gasket grind adjustment
100426	51	Mounting sheet grind adjustment ProM Espresso
310731	53	Adjustment knob grind adjustment, service pack
100978	54	Grind adjustment lock ProM Espresso
100766	55	Scale ring interior toothed ProM Espresso
311067	56	Tapping screw ISO7049 DIN7981-2.9x9.5
100481	57	Pressure spring Grind adjustment ProM Espresso

Changes In The Spare Parts List:

VALID FROM VERS.	ARTICLE NO.	DRAWING NO.	DESCRIPTION	COMMENT
2.4	101017	40	Grinder casing cover EK8, service pack	new service packs for EK8
2.4	101019	41	Grinding disc set EK8 pro, service pack	new service packs for EK8
2.4	101022	42	Adjustment EK8 ProM Espresso, service pack	new service packs for EK8
2.4	101021	43	Belt / wheel EK8, service pack	new service packs for EK8
2.4	101018	44	Spout EK8, service pack	new service packs for EK8
2.4	101020	45	Rotating burr carrier EK8, service pack	new service packs for EK8
2.4	101023	46	Damper EK8, service pack	new service packs for EK8
2.4	100978	54	Grind adjustment lock ProM Espresso	replaces 100420 & 100385
2.5	102009	30	Front panel ProM Espresso, service pack	pre-assembled front panel
2.6	102180	44	Spout EK8 100-120V, service pack	new spout for version 100-120V
2.7	310468	20	O-ring 71 x 2m	new in spare parts list
2.8	100745	3	Top housing assembly. ProM Espresso	new in spare parts list