

K30 2.0

PREVENTIVE MAINTENANCE



www.mahlkoenig.de



K30 2.0 RECOMMENDED SPARE PARTS LIST

AMOUNT	DESCRIPTION	ARTICLE NUMBER
1	Hopper 1.5 kg, with lid	309560
1	Display complete	105994
1	Fan, complete	700447
1	Capacitor 50 μ F 250 V AC, for build in grinder 100 - 127 V	302320
1	Capacitor 16 μ F 400 V AC, for build in grinder 220 - 240 V	308486
1	Flapper	310139
1	Burrs set Espresso	306715
1	Micro switch, service pack	700448
1	Portafilter support, service pack	306719
1	Spout, service pack	306724
1	Finger protection crown, service pack	700444
1	Deco panel matt black, service pack	700424
2	Deco panel matt white, service pack	700425

K30 2.0 BASIC STOCK PROPOSAL CLEANING PROCESS

1. CLEANING:

Always unplug the coffee grinder before cleaning.

- Apply dry cleaning only. If necessary use suitable mild „dish“ washer detergent
- No alkaline cleaning agent must be used for cleaning (affects-flavour)
- Do not spray coffee grinder with water and/or steam (risk of short circuit)
- Clean your grinder periodically, at least once a week.
- Please use MAHLKÖNIG GRINDZ™

Cleaning of housing:

- Use paper towel along with mild dish washer detergent to clean the housing, cover lid and inside the hopper

Cleaning of spout tube:

- Use a vacuum cleaner to exhaust the discharge tube. The use of brushes can lead to the damage of the built-in flappers resulting in an inaccurate grinding result.

Periodic checking of the grinder, burrs and grinding quality must only be performed by competent service personnel and/or trained staff.

2. ROUTINE CHECK:

Indications:

- Reduction of the output of the grinder.
- Temperature increase of the ground coffee
- Inconsistent grind
- Increased amount of dust
- Grinder clogs more often

3. MAINTENANCE:

Short-term maintenance every 2 weeks

- Outside cleaning including the hopper
- Use GRINDZ™

Long-term maintenance once a year

- Thorough cleaning of the grinder including the opening of the grinder housing and removing of all coffee residues
- Change of burrs
- Checking calibration and re-calibrate, if necessary



Hemro International AG

Längenstrasse 34 | 8184 Bachenbülach, Schweiz

T: +41 44 864 18 00 | F: +41 44 864 18 01

info@hemrogroup.com | www.hemrogroup.com