

K30 TWIN

PREVENTIVE MAINTENANCE



www.mahlkoenig.de



K30 TWIN RECOMMENDED SPARE PARTS LIST

AMOUNT	DESCRIPTION	ARTICLE NUMBER
1	Power board K30 TWIN 200 - 230 V, service pack	309404
2	Running capacitor 10 μ F (200 - 230 V / 50 Hz)	305743
2	Grinding disc set EK11 - K30 Vario	306715
10	Silicone flapper \varnothing 17 mm	310139
10	Steel flapper \varnothing 15.8 mm (ser.no. 515745 - 523560 only)	100584
10	Silicone flapper \varnothing 15.8 mm (exchange for steel flapper only!) Serial.no. 515745 - 523560 only)	101518
1	Processor board with display (software on request)	308332
1	Micro switch service pack	306720
1	Tool for disc change in EK11b built in grinder	101066
1	Grind adjustment key K30 TWIN	306590
1	Fan grid, service pack	309421
1	Fan 24 VDC 80 x 80 x 15	310673

K30 TWIN BASIC STOCK PROPOSAL CLEANING PROCESS

1. CLEANING:

Always unplug the coffee grinder before cleaning.

- Apply dry cleaning only. If necessary use suitable mild „dish“ washer detergent
- No alkaline cleaning agent must be used for cleaning (affects-flavour)
- Do not spray coffee grinder with water and/or steam (risk of short circuit)
- Clean your grinder periodically, at least once a week.
- Please use MAHLKÖNIG GRINDZ™

Cleaning of housing:

- Use paper towel along with mild dish washer detergent to clean the housing, cover lid and inside the hopper

Cleaning of spout tube:

- Use a vacuum cleaner to exhaust the discharge tube. The use of brushes can lead to the damage of the built-in flappers resulting in an inaccurate grinding result.

Periodic checking of the grinder, burrs and grinding quality must only be performed by competent service personnel and/or trained staff.

2. ROUTINE CHECK:

Indications:

- Reduction of the output of the grinder.
- Temperature increase of the ground coffee
- Inconsistent grind
- Increased amount of dust
- Grinder clogs more often

3. MAINTENANCE:

Short-term maintenance every 2 weeks

- Outside cleaning including the hopper
- Use GRINDZ™

Long-term maintenance once a year

- Thorough cleaning of the grinder including the opening of the grinder housing and removing of all coffee residues
- Change of burrs
- Checking calibration and re-calibrate, if necessary



Hemro International AG

Längenstrasse 34 | 8184 Bachenbülach, Schweiz

T: +41 44 864 18 00 | F: +41 44 864 18 01

info@hemrogroup.com | www.hemrogroup.com