

E65S

PREVENTIVE MAINTENANCE



www.mahlkoenig.de



E65S RECOMMENDED SPARE PARTS LIST

AMOUNT	DESCRIPTION	ARTICLE NUMBER
1	Hopper, complete	700610
1	Back panel with power board 110 - 127 V	701578
1	Back panel with power board 220 - 240 V	701091
2	Noise protection mat	700715
1	Collecting tray	700698
1	Display, complete	700721
1	Spout, incl. spout guide	700707
1	Capacitor 60 μ F 250 VAC (for built-in grinder 100 - 127 V)	701084
1	Capacitor 16 μ F 440 VAC (for built-in grinder 220 - 240 V)	701083
4	Device feet	700727
1	Start button	700714
1	Portafilter support, complete	700708
1	Portafilter mounting, complete	700713
1	Grinding degree lock, complete	700711
10	Seal ring	700702
10	O ring	700705
3	Shock absorber	700716
1	Grinding degree slide	700701
10	Flapper	701583
1	Burrs set	306715

E65S RECOMMENDED SPARE PARTS LIST

AMOUNT	DESCRIPTION	ARTICLE NUMBER
1	Grind adjustment gear box, complete	700720
1	Spout mounting, complete	700717
1	Interlock, service pack	700712
1	Tools for burr change	700974
1	Hopper mini, complete	700995

E65S BASIC STOCK PROPOSAL CLEANING PROCESS

1. CLEANING:

Always unplug the coffee grinder before cleaning.

- Apply dry cleaning only. If necessary use suitable mild „dish“ washer detergent
- No alkaline cleaning agent must be used for cleaning (affects-flavour)
- Do not spray coffee grinder with water and/or steam (risk of short circuit)
- Clean your grinder periodically, at least once a week.
- Please use MAHLKÖNIG GRINDZ™

Cleaning of housing:

- Use paper towel along with mild dish washer detergent to clean the housing, cover lid and inside the hopper

Cleaning of spout tube:

- Use a vacuum cleaner to exhaust the discharge tube. The use of brushes can lead to the damage of the built-in flappers resulting in an inaccurate grinding result.

Periodic checking of the grinder, burrs and grinding quality must only be performed by competent service personnel and/or trained staff.

2. ROUTINE CHECK:

Indications:

- Reduction of the output of the grinder.
- Temperature increase of the ground coffee
- Inconsistent grind
- Increased amount of dust
- Grinder clogs more often

3. MAINTENANCE:

Short-term maintenance every 2 weeks

- Outside cleaning including the hopper
- Use GRINDZ™

Long-term maintenance once a year

- Thorough cleaning of the grinder including the opening of the grinder housing and removing of all coffee residues
- Change of burrs
- Checking calibration and re-calibrate, if necessary



Hemro International AG

Längenstrasse 34 | 8184 Bachenbülach, Schweiz

T: +41 44 864 18 00 | F: +41 44 864 18 01

info@hemrogroup.com | www.hemrogroup.com